



- Standard Instrument Departures: LOX
- Standard Instrument Departures: RAF Brize Norton
- Terminal Approaches: LOX
- - - Terminal Approaches: RAF Brize Norton
- △ New co-located frequency paired VOR/DME

Figure 20 Standard Arrival and Standard Instrument Departure Routes • Terminal Approaches

Base chart: Copyright © 2000 Royal Air Force (AIDU). All rights reserved.
 Copyright © 2001 Pleiade Associates Ltd

27L / 28R runway approaches